

MIRADOR 111 CURTAIN A AM INSTRUCTION MANUAL

Quick Links

[Before Assembling Your Side Shade Screen](#)

[List of Parts](#)

[Assembly](#)

Table of Contents

[Table of Contents](#)

[Before Assembling Your Side Shade Screen](#)

[Important Safety Advice](#)

[List of Parts](#)

[Assembly](#)

[Operating Your Side Shade Screen](#)

[Care & Maintenance](#)

[Warranty & Complaints Procedure](#)

[Other ManualsLib Projects](#)

SIDE SHADE SCREEN

INSTRUCTION MANUAL



THANK YOU FOR PURCHASING THE MIRADOR SIDE SHADE SCREEN!

This manual will provide you with clear and detailed instructions on how to safely and correctly assemble and maintain your side shade screen, to ensure it brings you many years of use and enjoyment.

IMPORTANT

Please read the entire manual carefully before assembling and using your side shade screen, and please ensure the manual is kept in a safe place for future reference.

Any use or modification to the side shade screen not included in this manual shall be considered as improper use, which may cause considerable danger to users and property and will void the product warranty.

Please only use this product for its intended purpose within a residential environment. Failure to do so will void your warranty.

We reserve the right to make changes for product improvements.

For parts and customer service, please call +1 (877)-506-4777 in the U.S. and Canada (English and Spanish) Monday - Friday: 6:30 am - 4:30 pm, Saturday - Sunday: 8:30 am - 4:30 pm, Pacific Time. Or email: support@miradoroutdoor.com

Digital instruction manual is also available on our official website www.miradoroutdoor.com for your reference.

TABLE OF CONTENTS

- Before Assembling Your Side Shade Screen	3
- Important Safety Advice	4
- List of Parts	6
- Assembly	7
- Operating Your Side Shade Screen	14
- Care & Maintenance	15
- Warranty & Complaints Procedure	16

BEFORE ASSEMBLING YOUR SIDE SHADE SCREEN

WARNING: Important safety instructions. Follow all instructions, since incorrect installation can lead to severe injury.

Make sure you have all the tools required for assembling your side shade screen

In order to assemble your side shade screen safely and correctly, please ensure you have access to the following tools and accessories, all of which are not provided.



Check to ensure there are no missing parts:

Before you begin assembly, please check that you have all the parts required to assemble your side shade screen. Please also carefully check that the quantity of parts match with that of the model you have purchased.

If any parts are missing, please refer **Warranty & Complaints Procedure** to contact customer service before beginning the assembly.

Prepare the parts you will need for each step:

In the **Assembly** section of the manual, each step indicates the necessary parts and quantities required to complete the step. We recommend that you prepare the parts you will need for each assembly step. Doing this will save you time and effort during assembly. If possible, place the parts on cardboard or other soft surface to protect from scratching the painted surfaces.


IMPORTANT SAFETY ADVICE

For the safety of all persons assembling and using the side shade screen , it is important to follow the safety guidelines below.


Lift the screen during snowfall rainy or windy days to prolong the servicelife of the product.




Always wear appropriate work shoes, gloves and eye protection when working.



Work well away from power lines, particularly when handling metal parts.



If using power tools or a ladder, always follow the manufacturer's safety instructions.



Make sure the side shade screen complies with local building regulatory codes.



Working at heights can be dangerous. Always wear protective clothing to prevent injury in the event of a fall.



Only use ladders and scaffolding with a sufficiently high load bearing capacity.



Please recycle packaging where possible.




Only use replacement parts that are approved by the manufacturer.



✓ Approved

Keep clothing and body parts away from the side shade screen to prevent them from getting caught in the moving parts.



After prolonged use we recommend you check all the fittings are tightened securely.




Install on non-Mirador branded pergola will void the product warranty and can damage the operation mechanism.



Mirador®

It is recommended that two people lift the side shade screen once assembled. Ensure you lift with the correct posture & technique.



Do not attempt to assemble the product if you are tired, or after consuming alcohol.



Hot items such as recently used grills, fire pits etc. must not be stored under or close to the side shade screen.



Keep children and pets away from the assembly area until the work is completed.



Do not attempt to assemble the side shade screen in windy or wet conditions.



Do not touch moving parts during operation.




Dispose of all plastic bags safely. Keep them out of the reach of children.



Changes to the design or configuration of equipment may not be made without consulting the manufacturer or authorized representative.



LIST OF PARTS

	REF	Part Name	QTY
A		Right side panel	1
B		Left side panel	1
C		Roller	1
D		Screw ST5.5x16mm	12+3
E		Baffle	2
F		Screw ST4.2x20mm	2
G		Drill Bit φ4x55mm	2
H		Hex key	1



Assembly Video

ASSEMBLY

1. Component disassembly

1A

Using hex key **H**, remove the built-in screws **I** and washers **J** at both ends of the roller **C**.


Notice:

The unscrewed screws **I** and washers **J** will be used in step **2D**. Please keep them properly.

H x 1



C x 1



1B

Unscrew screws **I** and worm gearbox **V** from the right side panel **A**.


Notice:

The unscrewed screws **I** and worm gearbox **V** will be used in step **2C**. Please keep them properly.

H x 1



A x 1



2. Side panel and roller assembly



2A

Lay 2 side panels (**A** & **B**) and roller **C** on the floor.


Insert zipper teeth on both sides into corresponding plastic rails simultaneously, and fix them with baffle **E** and screw **F**, using a phillips screwdriver.

E x 2  **F** x 2 

C x 1 

B x 1 


A x 1 



2B


After inserting the worm gearbox **V** onto the roller **C**, slide down the roller **C** and align the shaft into the holes on both sides panels (**A** & **B**).

H x 1  **V** x 1 



2C


Fix the roller **C** and the worm gearbox **V** to the right side panel **A**.



H x 1  **I** x 2 

2D

Assemble the side panels (**A** & **B**) and roller **C** with screw **I** and gasket **J** on each side, using a hex key **H**.



H x 1 


I x 2  **J** x 2 

3. Side shade screen assembly


This phase requires two persons and at least two stepladders.
Make sure that the stepladders are standing securely to avoid falling.
Only use ladders suitable for this kind of installation work.

**3A**

Use a leveler to measure against both of the inner sides to ensure that the corner pillar is straight and level.

**3B**

Two people are required to put up the whole screen assembly to make sure both metal rails are lifted simultaneously.

**2 PERSONNEL REQUIRED**




3C

Adjust the position to ensure that the side panels (**A** & **B**) are parallel to the pillars.

Using tape measure to check if the distance from both edge of the side panels (**A** & **B**) to the pergola's pillar is the same.

Size (m/ft)	L		X	
	(mm)	(inch)	(mm)	(inch)
3/10	2825	111.2	16	0.63
	2806	110.5	6.5	0.26
	2795	110.1	1	0.04




3D

Drill a hole on each pillar according to the position of the top screw hole on side panels (**A** & **B**). And fix with a screw **D** on each side.

Notice:

Please do not tighten the screws completely yet.



D x 2



G x 1





3E

Adjust the side panels to ensure they are parallel to the pillars.

Drill the remaining holes and fix with screws **D** after the appropriate location is determined, using a electric screwdriver.


Notice:

Remember to tighten the top screws completely.

D x 10







G x 1




3F

Remove the crank from the pergola and use the same crank to operate the side shade screen.


Insert the end of the crank into the worm gearbox **V**, and turn until the crank locks firmly in place.



4. End of assembly



OPERATING YOUR SIDE SHADE SCREEN




To open the side shade screen, turn the crank handle clockwise;
To close the side shade screen, turn the crank handle counter clockwise.

Enjoy your new side shade screen and pergola!

CARE & MAINTENANCE

Dust and dirt will collect on the screen and will require periodic cleaning.



Use a water/detergent mixture and a soft clean cloth to clean the screen.



Air dry or wipe with a soft clean cloth.



In coastal areas, it is recommended that you frequently spray the screen with water to reduce accumulation of salt and dirt.



For more soiled areas, rinse the surface with clean water from top to bottom.



Do not use any petroleum based spray lubricant.



Petroleum based

WARRANTY & COMPLAINTS PROCEDURE

For terms and conditions of our limited warranty, please visit www.miradoroutdoor.com or contact your local Mirador sales representative.

Complaints procedure:

- The complaint must include an order number or transaction number. Goods without an order number or transaction number are not covered under the warranty.
- The complaint must include a detailed description of the defect, the name of the company which assembled the product if 3rd party was used and the date when the defect was discovered.
- At Sorara Outdoor Living USA Inc's discretion, customer must offer supplier the photos/videos of the issue/damaged parts. Otherwise, supplier reserves the right to refuse replacement parts or credit.
- Please save a copy of your purchase receipt.

Contact:

Customer Service: support@miradoroutdoor.com

Need Assistance? Call +1 (877)-506-4777

Hours of Operation:

Phone Support: Monday - Friday: 6:30 am - 4:30 pm, Saturday – Sunday: 8:30 am – 4:30 pm, PST.

Email Support: We are available 24 hours a day. Please allow up to 24 hours for a response.

Chat With Us Online: miradoroutdoor.com, Monday - Friday: 5:30 am - 2:00 pm, Saturday – Sunday: 8:30 am – 4:30 pm, PST.

Note: Our team is available to assist you during these hours. If you have any inquiries or require support outside of these hours, please leave a voicemail, send an email, or use our online contact form. We will get back to you promptly during the next available support hours. Thank you for choosing Mirador Outdoor!

CERTIFICATION INFORMATION

Declaration of performance (DOP)

Reference no. DOP0003

Product name and type

Mirador Guided roller blind/ Roller blind

Model name/ Unique identification code of the product:

111 Curtain A Am, 111 Curtain B Am, 111 Curtain C Am,

A:

for 3x3, for 3x3.6, for 3x4, for 3x5.3, for 3x6, for 3x7.2

for 3.6x3.6, for 3.6x4, for 3.6x5.3, for 3.6x6, for 3.6x7.2

88 Curtain A Am, 88 Curtain B Am, 88 Curtain C Am,

A:

for 3x2, for 3x2.4, for 3x3, for 3x4, for 3x5, for 3x6

80/88 Roller Blind Am,

A:

3, 3.6, 4

111 Pull Down Screen Am,

A:

3, 2.56, 3.6, 4

Purpose of Usage:

External use in buildings and other construction works

Manufacturer:

Zhejiang Zhengte Co., Ltd.

No.558 Linhai Ave., Linhai, 317000, Zhejiang, China , PRC

Documentation officer:

Ziad Zhao

Zhejiang Zhengte Co., Ltd.

No.811 Oriental Ave., Linhai, 317004, Zhejiang, China

System for assessing and verifying the constancy of performance according to Annex V of the Construction Products Directive 305/2011/EC

System 4

Declared performance (Excluding the structural part):


Wind resistance = Class 1

Standard: EN 13561:2004+A1:2008

The performance of the product identified above is in conformity with the declared performance in declaring performance; This declaration of performance is issued under the sole responsibility of the manufacturer identified above.

Zhejiang

15.12.23



(Chairman/President)

more to
enjoy

MIRADOR® is a registered trademark
of Zhejiang Zhengte Co., Ltd.
© 2024 Sorara Outdoor Living USA .
All rights reserved.



Printed on 100%
post-consumer
recycled paper



FOLLOW US ON
WWW.MIRADOROUTDOOR.COM
Instagram: @miradoroutdoor YouTube: @MiradorOutdoor
Facebook: @miradoroutdoor TikTok: @miraadoroutdoor

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ Languages